

Strider Pen Kit Instructions

You will need:

Drill bits: 3/8"
Strider/Swift Click Bushing

Drill, Tube & Square your blanks & mount on your mandrel



Turn your blank down to the bushings. Polish & finish blank

Lay out your parts based on the diagram below



Assembling the pen

1. Press the front tip onto the center section.
2. Insert the ink refill and screw.
3. Thread on the transmission.

4. Thread on the transmission.
5. Put clip into upper section and press in to one side of tube.
6. Slide blank onto center section and press together by hand.